
Inde-Pendants Family 32L Cylinder Open Ceiling Types


Installation instructions for 32L-C-P-ID 32L-C-P-D



Document No. 510650-02

32L Inde-Pendants: Cylinder (Open Ceiling Applications)

Supplied by Litecontrol



Supplied by Contractor

- Standard 4 X 4 octagonal outlet box with mounting hardware Feed cord
- Wire nuts


Tools Required

- Wire cutters/strippers Tape measure Marker

- Felco-type cable cutters 1/4" Socket with wrench or flat-head screwdriver
- Level


510650-02

J-box Installation



Completed J-box installation should match **Figure 1** on page 6.

510650-02




- . Measure 1" from bottom of the cable and mark the location
- 2. Strip 1" of the metallic exterior and plastic interior off of the coaxial cable (using 16 gage wire strippers), leaving 1" of the inner aircraft cable exposed. (Left Image)

 3. Twist and move the metallic exterior jacketing up so that 1/8" to
- 1/4" of the **plastic interior** is exposed.

IMPORTANT: Do not let the exterior metallic sheathing and the inner aircraft cable touch. (Right Image)

- 1. Match the letter indicators on the **Uplight Sub Assembly** with the letters on the Cylinder to ensure correct fixture orientation.
- 2. Loosen the Gripper Lock Nuts
- 3. Feed the cables into their respective grippers as far as they'll go in 4. Check that the Cylinder is level and adjust the cables accordingly before fully securing the gripper lock nuts.
- . Make the wiring connections as shown in the above image between the blue and red wires in the Cylinder and Uplight Sub Assembly. If there is no uplight, no wiring is required to the Uplight Sub Assembly (no red wire connections).
- 2. Using three wire nuts, connect red wire with red wire, and each blue wire with respective blue wire according to the alignment between the Cylinder and the Uplight Sub Assembly.

Cylinder Installation



flush with Surface X. The Outer Grippers should not be exposed at all above the voids.

Note: If the Outer Grippers come off of the Exterior Metallic Sheathing and are no longer making contact with it, secure them back on the cables by removing the cable from the gripper completely, removing the Outer Gripper, twisting/tightening the Exterior Metallic Sheathing, and putting the Outer Gripper back on the cable by completely loosening the plastic cap on the gripper and feeding the cable into the Outer Gripper while twisting the Outer Gripper. The Outer Grippers must be in contact with the Exterior Metallic Sheathing for the fixture to illuminate.

- Remove the **8-32 Mounting Screw** from the Cylinder.
- Lower the Uplight Sub Assembly onto the Cylinder
- Reinstall 8-32 mounting screw thereby securing the Uplight Sub Assembly to the Cylinder.

For Cylinder only fixture (left), the installation is now complete. Reverse instructions to uninstall fixture and J-box.

For Cylinder with Ring fixture (right), see Ring installation sheets to complete installation.

Completed Cylinder installation should match Figure 2 on page 6.

510650-02

Figure 1 Completed J-box installation







Figure 2 Completed fixture installation






WIRING DIAGRAMS

APPLICABLE FIXTURE TYPES:
• 32L-C-P-ID



STANDARD WIRING (CAN ALSO BE USED IN NIGHTLIGHT APPLICATIONS)


ALTERNATIVE FIELD WIRING OPTIONS



WIRING DIAGRAM

(NO UPLIGHT)

APPLICABLE FIXTURE TYPES:
• 32L-C-P-D



Cylinder Label Positioning

If fixture is damaged or additional assistance is needed, call the number on the label to speak with a Litecontrol representative

CONTACT LITECONTROL MODEL: 32L LMA FOR REPLACEMENT PARTS DATE: ___/___ \$\frac{1}{59392}\$

