SUB-TRANSMISSION OPTICAL MONITORING AND SECTIONALIZING SOLUTION Quick Start Guide







PAGE NO.

Introduction	4-5
1. Air Break Switch Installation	6
2. Optical Sensor Installation	7
2.1 Insulation Removal	7
2.2 Line Cleaning	7
2.3 Overhead Optical Line-Post Sensor	8
3. Radio and Security Gateway Installation	14
4. m410 RTU Controller Cable Connections and Power Up	15
5. m410 RTU Configuration and Set Up	20
5.1 Download GUI Executable and Connect to m410	20
5.2 Set m410 IP Address to Security Gateway's Subnet	20
5.3 Configure DNP Settings	21
5.4 Apply New Configuration Settings and Reboot	21
6. Connect m410 RTU to Security Gateway	23



PAGE NO.

PAGE NO.

Figure 1. Sensor Sectionalizer Pole Assembly	6
Figure 2. Optical Line Post Sensor	8
Figure 3. Optical Line Post Sensor Combination Voltage & Current, 4-72kV Rating	9
Figure 4. Optical Line Post Sensor - Mounting	10
Figure 5. Optical Line Post Sensor - Grounding	11
Figure 6. Optical Line Post Sensor - Opening Clamp	11
Figure 7. Optical Line Post Sensor - Reversible Wire Clamp	12
Figure 8. Optical Line Post Sensor - Secure Wiring Clamp	12
Figure 9. Optical Line Post Sensor - Securing Current Concentrator	13
Figure 10. RTU and Motor Operator Control Cabinet	14
Figure 11. Terminal Block Wiring	14
Figure 12. m410 RTU Controller - Top View	15
Figure 13. m410 RTU Controller - Front View	15
Figure 14. m410 RTU Controller – Cable Connections	16

Figure 15. m410 Bay 4 Sectionalizing Control Module – Connectors	17
Figure 16. Motor Operator – Communications Port	17
Figure 17. m410 Power Connector	18
Figure 18. Cabinet Power Breakers	18
Figure 19. m410 Status Indicator	19
Figure 20. m410 Optical Sensor Status Indicators	19
Figure 21. m410 IP Address Configuration	20
Figure 22. m410 DNP Configuration	21
Figure 23. m410 – Apply Configuration Changes	21
Figure 24. m410 Confirm Configuration Changes	22
Figure 25. m410 Select Configuration Changes To Apply	22
Figure 26. m410 Confirm Reboot	22
Figure 27. m410 2nd Confirm Reboot	23
Figure 28. m410 RTU - Communications	23



Hubbell Power Systems Utility Automation, Switching & Fusing



Introduction

The Hubbell Power Systems' sub-transmission optical monitoring and sectionalizing solution is designed for 46kV to 69kV overhead sub-transmission system applications. The sensors and RTU equipment measure bi-directional power flow, power quality and report fault events. The state-of-the-art optical design provides unmatched safety and accuracy. When provided with the Hubbell FlexMO motor operator and switch assemblies, the combined solution enables rapid isolation and sectionalizing of faulted segments to drastically improve outage and SAIDI performance metrics. This integrated kit from Hubbell saves utilities valuable time, effort, and project costs.

WARNING: De-energize and properly ground any applicable and adjacent equipment before performing any installation or maintenance. Work should only be undertaken by qualified personnel.

CAUTION: Follow your utility's approved safe work practices for handling and configuration of all equipment.



Suggested Grounding



For proper operation this system must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. The system is equipped with a connection terminal for powering and grounding the system.





WARNING: Do not use or install product that has damaged packaging or has been exposed to the elements for prolonged periods of time.



Hubbell Power Systems Utility Automation, Switching & Fusing

1. Air Break Switch Installation

Install the air break switch per the Hubbell switch installation manual - please consult your local Hubbell Customer Service Representative.



Figure 1. Sensor Sectionalizer Pole Assembly



2. Optical Sensor Installation

The optical sensor installation is broken out into the following steps:

2.1 Insulation Removal

Any covering on the line that will be in the way of direct connection of the sensor conductor clamps needs to be removed to install either style of overhead sensors. This includes but is not limited to tree guards, line guards or any other insulation that may cover the bare conductor.

2.2 Line Cleaning

It is imperative for accurate measurement that all sensors are secured and maintain a solid direct connection to bare conductor. For each location an optical line post sensor is to be installed, the exposed conductor or busbar should be cleaned of any debris or residue to a clean like-new surface. Where this is not feasible, a new conductor may need to be installed.





2.3 Overhead Optical Line-Post Sensor A CAUTION: Installation may involve heavy lifting. To prevent personal injury, two persons should perform lifting activities as necessary.



Figure 2. Optical Line Post Sensor, Combination Voltage & Current, 4-72kV Rating





- A. Power Conductors
- **B. Line-Post Sensor**
- C. Optical Fiber Cable
- **D. NEMA Enclosure**
- E. Current Concentrator
- F. Current Concentrator Bolts
- G. Insulator Body
- H. Optical Fiber Cable
- I. Modular Connector
- J. Reversible Wire Clamp
- K. Reversible Wire Clamp Bolt
- L. Ground Reference Lug*
- M. Current Flow Designation
- **N. Sensor Mounting Plate**

Figure 3. Optical Line Post Sensor



When horizontal arm is prepared, the sensors can be mounted directly to it, via a standard ³/₄-10 UNC mounting bolt or line post stud. Additionally, there are four ½-13 threaded inserts in the bottom of the sensor, for added mounting strength. See Figure 4 for bolt pattern layout. Sensors can be installed vertically or horizontally. For horizontal installation, the cantilever rating for the sensors is 3000 pounds based on this bolt circle configuration.



Figure 4. Optical Line Post Sensor - Mounting



Place grounding conductor into ground reference lug and tighten nut. Hubbell recommends using 6 AWG wire. Sensor reference ground should be bonded to a local ground rod. The ground reference connection is not a path from voltage potential to ground, it is only a ground reference to eliminate any outside interference with the e-field for voltage measurement from any other objects in the vicinity of the sensors. For more information regarding grounding, please reach out to your local Hubbell representative.



Figure 5. Optical Line Post Sensor - Grounding

2.3.3

After sensor has been mounted on the arm, remove the current concentrator clamp from the sensor body by removing current concentrator bolts and open the reversable wire clamp by loosening the two bolts and turning the clamp 180 degrees.







Place the conductor on the top groove of the sensor. The reversable wire clamp has two sizes of grooves on the top and bottom designed to be used with different size cables. To adjust the clamp to different size wire, just flip the clamp upside down.



Figure 7. Optical Line Post Sensor - Reversible Wire Clamp

2.3.5

Close reversable wire clamp and tighten bolts. Applicable torque is 37.9 n-m.



Figure 8. Optical Line Post Sensor - Secure Wiring Clamp



Place current concentrator over conductor cable and tighten bolts. Applicable torque: 21.6 n-m.



Figure 9. Optical Line Post Sensor - Securing Current Concentrator

If there is any additional cable slack, it can be either bundled at the top of the pole or inside of the enclosure. Please note: The suggested bend-radius for the optical cable is 11". Anything smaller than this may cause damage to the cables. We recommend protecting the optical cable with standard U-Guard or conduit.



3. Radio and Security Gateway Installation

Mount customer-provided radio and security gateway devices on the inner door locations indicated in Figure 10 - RTU and Motor Operator Control Cabinet.



Figure 10. RTU and Motor Operator Control Cabinet

CAUTION: Risk of Electric Shock. To prevent electrical shock, turn off power to the cabinet breaker before installing or servicing unit. Equipment must be installed and serviced by competent personnel who have been trained and understand proper safety procedures. Failure to follow precautions can result in personal injury and equipment damage. Do not install or operate unit if any damage is noticed.

Connect radio and gateway power supply cables to cabinet power using the terminal block connections as indicated in Figure 11 - Terminal Block Wiring



Figure 11. Terminal Block Wiring

Configure radio and security gateway per vendor specifications



4. m410 RTU Controller Cable Connections and Power Up

Connect optical sensor cables to the m410 RTU controller per Figure 14 - m410 RTU Controller – Cable Connections. The A phase sensor cable must be connected to Bay 1, B phase must be connected to Bay 2, and C phase must be connected to Bay 3.

Phase Sensor Cable	Connects to
А	Bay 1
В	Bay 2
С	Bay 3



Figure 12. m410 RTU Controller - Top View



Figure 13. m410 RTU Controller - Front View





Bay 4 Sectionalizing Control Module Motor Operator Control Cables

Figure 14. m410 RTU Controller - Cable Connections



Connect motor operator control cables to sectionalizing Control module connectors in Bay 4 per Figure 15- m410 Bay 4 Sectionalizing Control Module - Connectors and Figure 16 - Motor Operator - Communications Port.

- Connector 1: Control outputs from 4th bay control module to motor operator controller.
- Connector 2: Switch position status inputs from motor operator to 4th bay control module.
- UART Comms: Serial port communications between control module and motor operator port J17.



Figure 15. m410 Bay 4 Sectionalizing Control Module - Connectors



Figure 16. Motor Operator – Communications Port



Connect the m410 power connector to the cabinet 12-24 Vdc terminal block per Figure 17 - m410 Power Connector if not already connected.



Figure 17. m410 Power Connector

Connect the motor operator power cord to the cabinet power if not already connected.

Wire the cabinet to 120V mains power and turn on cabinet breakers per Figure 18 - Cabinet Power Breakers to enable cabinet power.



Figure 18. Cabinet Power Breakers



Allow approximately 60 seconds for the m410 to boot up, load system files and perform self-testing. The m410 status indicator LED is located on the top of the device per Figure 19 - m410 Status Indicator. Verify that the status indicator is solid green after boot up. If the status indicator is red, orange or flashing green, consult the m410 manual for troubleshooting the m410 status visual indicator LED.



Figure 19. m410 Status Indicator

The m410's default IP address is 169.254.0.200. The user's laptop must be initially configured for the same subnet as the m410. Set laptop IP address to 169.254.0.201. Connect the laptop Ethernet port to the m410 RJ45 connector with an Ethernet cable. Run the Micatu GUI executable to launch the GUI application.



Figure 20. m410 Optical Sensor Status Indicators



5. m410 RTU Configuration and Set Up

5.1 Download GUI Executable and Connect to m410

To set up the m410 controller, the Micatu GUI application is required. Please contact DL-Trinetics-Marketing@ hubbell.com to obtain a copy of the GUI executable file.

The m410's default IP address is 169.254.0.200. The user's laptop must be initially configured for the same subnet as the m410. Set laptop IP address to 169.254.0.201. Connect the laptop

5.2 Set m410 IP Address to Security Gateway's Subnet

To enable the m410 to communicate with the customer-provided radio and security gateway, the m410 must be configured with a new IP address on the same subnet as the security gateway. In the GUI application, select the Network Settings menu.

- Set IP Address Type to Static
- Configure IP Address, Subnet Mask and Default Gateway to match the security gateway settings.

Faults / Harmonics	Scale Factors	DNP Point
IP Address Type:	O DHCP	
1	✓ Use Static Fallback	
Static Configurati	on	
IP Address:	192.168.1.21	
Subnet Mask:	255.255.255.0	
	192 168 1 1	

Figure 21. m410 IP Address Configuration



5.3 Configure DNP Settings

To enable the m410 to communicate to a SCADA system, the DNP Outstation and Master settings must be configured in the Sessions menu.

m410 Modular Optic	cal Sensor Platform S	ummary SN: BC	011900008	User: <u>Home</u>	root <u>Sign Out</u>		
m410 Topology Status	Sensor Measurements	Sensor Configura	ation DNP Co	nfiguration		System Ti	me: 11/01/2021 07:54:37 PM
	PHASE ID RG235 (UNK STATUS) & kV: .8 A: 8.9 kW: 3.3	PHASE ID RG235 (UINK STATUS) & KV: 1.819 A: 7.8 KW: 12.8	PHASE ID RG235 (UNK STATUS) 7 kV: 1.922 A: 8.2 kW: -13.5			PORT 2 3 2 3 3 5 5 5 5 5 5 1 5 5 5 5 5 1 5 5 5 5 5 1 5 5 5 5 1 5 5 5 5 5 5 1 5	
Faults / Harmonics	Scale Factors	DNP Point	Session	ystem Monitoring	Network Settings	Factory	Configuration
DNP Address Outstation: Master:	78 3						^
Analog Points Variation							
Default Static Variation: Default Event Variation:	5 - Single-precision floating poi 7 - Single-precision floating poi	int (32-bits) with flags int (32-bits) with time stamp	2	~			
Royart							~
m410 Modular Optical Senso Configuration Utility	or Platform						MICATU

Figure 22. m410 DNP Configuration

5.4 Apply New Configuration Settings and Reboot

After changes are made, the m410 must be instructed to apply the new configuration settings and reboot. From the Configuration menu, select Apply Configuration.

Ignore potential warnings about O-Ratio values and click OK.

Faults / Harmor	Scale Factors	DNP Point	Session	System Monito	Network Settin	Factory	Configuration
Where is your conf	iguration located?			m410 Device			
O Local File	m410 Device			Available Configura	ations:		
Local File							
Configuration Fil	e Location:						
			Browse				
							configuration
						Арр	oly Configuration

Figure 23. m410 – Apply Configuration Changes





Figure 24. m410 Confirm Configuration Changes

When prompted to select which configuration changes to apply, select checkboxes for both OPP Systems and Network, then click Apply.

Select config	uration(s) to apply	y to the M410
✓ OPP System	✓ Network	System Monitoring
Apply		Cancel



m410 Modular Optical Sensor Platform	Summary SN: BO11900008	User: root <u>Home Sign Out</u>	
m410 Topology Status Sensor Measurements	Sensor Configuration DNP C	onfiguration	System Time: 02/23/2022 09:27:35 AM
PHASE RG235 UNK STATUS of KY: 4.343 A: 48.7 KW: 194.8 Faults / Harmonics Scale Factors When is your configuration located?	PHASE ID PHASE ID RG235 RG235 UNK STATUS UNK STATUS KY: 4.860 KY: 4.860 KY: 1.000 KW: -181 Image: State of the stateo	s set to static.After reboot, this to the M410 via the static IP.	Port 2 9.9 9.9 9 2.1 8.6 8.6 8 3.044 9.0 9.0 9 2.1 9.0 9.0 9.0 9 2.1 9.0 9.0 9.0 9 7.1 9.0 9.0 9.0 9 7.1 9.0 9.0 9.0 9 Factory Configuration 6
O Local File O m410 Device		OK Cancel	
Configuration File Location:	Browse		
m410 Modular Optical Sensor Platform Configuration Utility			Load Configuration Apply Configuration
🗉 🔎 🖄 📰 🚶 🕲 💽 🔹	i 🐝 🛤 🕷 🌖 🔤 🌉 🕔	v 🙉 🚾 吵 🗡 🚥 :	

Figure 26. m410 Confirm Reboot



The application will provide a reminder that the m410's IP address is being changed. For any further configuration of the m410 via the laptop and GUI, the laptop will need to use a different IP address on the newly configured subnet. Click OK to proceed with the reboot.

m410 Modular Optical Sensor Platform Summary	SN: BO11900008	User: root Home Sign Out	
m410 Topology Status Sensor Measurements Sen	sor Configuration DNP Configuration		System Time: 02/23/2022 09:27:35 AM
PHASE ID PHASE ID RG235 RG UINK STATUS Image: Comparison of the state of the sta	PHASE ID PHASE	e affect until	Configuration
Where is your configuration located? Local File Configuration File Location: Browse m410 Modular Optical Sensor Platform Configuration Utility	Yes	No	Load Configuration
📲 A 🖽 🔢 🦹 🕲 💽 💶 📸 🛢	• 🐮 🌖 🚾 🛃 🖤 🧔 🖷	🛯 吵 🗡 🔤 🗘 🚥 🔺 🎚 S	9:29 AM 9:23/2022 ♥

Figure 27. m410 2nd Confirm Reboot

6. Connect m410 RTU to Security Gateway

Connect an Ethernet cable from the security gateway (customer provided) to the m410 Port 2 RJ45 communications port per Figure 28 - m410 RTU Controller – Communications Ports. Verify that the IP addresses of the m410 and security gateway are on the same subnet.



Figure 28. m410 RTU - Communications Ports



These instructions do not claim to cover all details or variations in equipment, nor to provide for all possible conditions to be met with concerning installation, operation, or maintenance of this equipment. If further information is desired or if particular problems are encountered which are not sufficiently covered in this guide, contact Hubbell Power Systems.



©2022Hubbell Incorporated. Because Hubbell has a policy of continuous product improvement, we reserve the right to change design and specifications without notice. Printed in the U.S.A. | TD10332E_0322

hubbellpowersystems.com