-1/2" CEILING BOX NOT FURNISHED

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Follow label information and instructions concerning Wet or Damp Locations, installation near combustible materials, insulation, building materials, and proper lamping. Do not install in areas subject to combustible vapors or gases. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with the National Electrical Code and local codes. The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. Do not block light emanating from product in whole or part, as this may cause an unsafe condition. Do not allow items such as drapes, curtains, screens or the like to come into contact with the product or to block light from the product, as this may cause an unsafe condition.

INSTALLATION INSTRUCTIONS **ARCHITRAK[®] SYSTEM**

INSTALLATION INSTRUCTIONS

FOR AKTCSK TRACK STEM KITS

FOR USE WITH PRESCOLITE AKT ONE/TWO CIRCUIT TRACK SYSTEM ONLY. READ INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE TRACK SYSTEM SAVE INSTRUCTIONS FOR REFERENCE WHEN MAKING ADDITIONS TO OR CHANGES IN THE TRACK SYSTEM.

INSTALLATION

nstruction

U,

- 1. Refer to PRESCOLITE AKT series track for track installation instructions
- 2. Assemble stem to universal cross bar with two lock nuts. Mount cross bar to ceiling box with screws provided with ceiling box. Slide 4-1/2" square canopy up stem. Secure to universal cross bar with two flat head screws.
- 3. Assemble z bracket to track rail with screws provided through slots provided at ends or middle of track.

Slide plastic cover up stem. Secure stem to z bracket with two lock nuts provided. Slide cover down over z bracket assembly. 4. WHEN STEM KIT IS USED AS A POWER FEED YOU MUST USE A AKTCSK WH OR AKTCSK BL TRACK STEM WIRE COVER. INSTALL AS FOLLOWS.

- 1. Run suitable black, white, green code gauge wire through stem. Be sure to allow at least 10" of wire for wiring to connector. See wiring instructions provided with connectors AKTEF, AKTT, AKTSL
- 2. Connect black stem wire to hot wire usually black. White to white neutral. Green to green or bare copper ground wire. Use approved connectors (wirenuts).

WIRE WIRENUTS NOT FURNISHED

> CANOPY UNIVERSAL CROSS BAR

> > FLAT HEAD SCREWS STEM

> > > COVER

NOTE: WIRING IS PRESENT WHEN USED AS A POWER FEED

ONLY.

- Disgard plastic stem cover, replace with stem wire cover. 3.
- See notes 1, 2, 3, 4 and diagram below for stem assembly. 4

rescolite

Z BRACKET

PRESCOLITE AKT RAIL

www.prescolite.com



WARNING:

101 Corporate Drive • Spartanburg, SC 29303

WHEN INSTALLING OR USING THIS TRACK SYSTEM, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED. READ ALL INSTRUCTIONS. DO NOT INSTALL THIS TRACK IN DAMP OR WET LOCATIONS. DO NOT INSTALL ANY PART OF TRACK SYSTEM LESS THAN 5 FEET ABOVE FLOOR. DO NOT INSTALL ANY FIXTURE ASSEMBLY CLOSER THAN 6 INCHES FROM ANY CURTAIN, OR SIMILAR COMBUSTIBLE MATERIAL. DISCONNECT ELECTRICAL

POWER BEFORE ADDING TO OR CHANGING THE CONFIGURATION OF THE TRACK. DO NOT ATTEMPT TO ENERGIZE ANYTHING OTHER THAN LIGHTING TRACK FIXTURES ON THE TRACK TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK. DO NOT ATTEMPT TO CONNECT POWER TOOLS.

EXTENSION CORDS, APPLIANCES, AND THE LIKE TO THE TRACK SYSTEM.

With representatives offices in principal cities throughout North America. Copyright 2005, 08/05 revision, All Rights Reserved - Printed in U.S.A.

Hubbell Lighting, Inc.