

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Follow label information and instructions concerning Wet or Damp Locations, installation near combustible materials, insulation, building materials, and proper lamping. Do not install in areas subject to combustible vapors or gases. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. **All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with the National Electrical Code and local codes.** The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. Do not block light emanating from product in whole or part, as this may cause an unsafe condition. Do not allow items such as drapes, curtains, screens or the like to come into contact with the product or to block light from the product, as this may cause an unsafe condition.

INSTALLATION INSTRUCTIONS ARCHITRAK® SYSTEM

INSTALLATION INSTRUCTIONS

FOR AKTPFC TRACK POWER FEED FOR SUSPENDED CEILINGS

FOR USE WITH PRESCOLITE AKT TRACK SYSTEM ONLY.

READ INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE TRACK SYSTEM

SAVE INSTRUCTIONS FOR REFERENCE WHEN MAKING ADDITIONS TO OR CHANGES IN THE TRACK SYSTEM.

INSTALLATION

1. Refer to PRESCOLITE AKT series track for track installation instructions
2. For use with PRESCOLITE CONNECTORS AKTEF, AKTSL, AKTT, AKTX when used as a power feed in a tee bar ceiling.
3. **WARNING** Disconnect power at panel before installing track system.
4. Remove and discard cover from track connector. Keep one of the screws.
5. Remove the flat screw from the connector, gave this screw.
6. Slide connector under triangle shaped tearout, align hole in connector back plate with hole in 4" back plate, secure with flat head screw.
7. Insert connector into track rail. Follow instructions provided with connector, and track rails for proper installation. Bring flex wiring to back plate, secure with approved connectors, wire with instruction provided with connectors.
8. Locate 4" cover over connector, secure with screw removed from connector cover.

