

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 617-294-0100 (781-294-0100 as of 9-1-97).

GENERAL NOTE:

This installation sheet is used with aircraft cable assemblies when 14/4 SJT, 18/4 ST & 18/5 SJT feed cord is required.

1. To secure feed cord at fixture end of installation;
 - A) Strip off outer jacket of feed cord enough to make wiring connections.
 - B) Insert feed cord thru either 5/8" or 7/8" ko's located in fixture.
 - C) Slide a 7/16" flat washer onto feed cord from underneath knockout.
 - D) Crimp metal strain relief onto cord as shown in view.

