



PLAN VIEWS

GENERAL NOTES: (READ SHEETS COMPLETELY BEFORE STARTING)

- A) Litecontrol recommends that (1) abutting fixture be mounted to a Pattern Box before attaching to ceiling.
- B) Installation is similar for all types of Pattern Boxes.
- C) Pattern Box Covers and its mounting hardware are shipped loose in same carton.

INSTRUCTIONS:

- 1. If electrical feed is being brought into Pattern Box, remove a 5/8" KO in support strap. See View.
- 2. Attach Pattern box to abutting fixture with (2) 1/4-20 machine screws (shipped in polybag) thru holes in fixture end header and into holes in side of Pattern Box.

Note: Use lower offset hole for mounting a 1-lite direct fixture to pattern box, otherwise use center holes for mounting. Make sure all sides are flush with fixture before tightening screws.

- 3. PENDANT MOUNTING: (Cables or Stems are shipped separately)
- A) Position an Extruded Flat Strap underneath center hole in Support Strap and thread Cable or stem into Flat Strap.
- B) Mount another pendant to the opposite end of the abutting fixture per fixture installation instructions.
- C) Lift fixture/pattern box assembly up and mount pendants to ceiling.

 Wire feed may be brought thru 7/8" holes in sides of box into fixture wireway.
- D) Level assembly up or down by threading stems or cable studs into Flat Straps. Tighten all pendant hardware after leveling.
- 4. Attach any additional fixtures to the Pattern Box per above steps.
- 5. Place Pattern Box Covers onto top of Pattern Box and secure with 2 sheet metal screws (shipped in polybag).
- 6. Clean exterior sufaces with a general window cleaner.

