

INSTALLATION  
INSTRUCTIONS

FIXTURE TYPE \_\_\_\_\_

WALL COLOR SHIELD OPTION  
WALLSLOT 8400

Revised Mounting Location  
as of 1st Quarter 2012

P/C 510576-1000

PG. 1 OF 1

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.  
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

**NOTES: PRIOR TO STARTING**

- A. WALL SURFACE SHOULD BE FINISHED A MINIMUM OF 7" ABOVE CEILING.
- B. WALL COLOR SHIELDS ARE SHIPPED IN 96" LENGTHS: SAWCUT TO SUIT FIELD CONDITIONS. SHIELDS ARE USED WHEN PAINTED WALL SURFACE IS A COLOR OTHER THAN WHITE OR OFF WHITE.
- C. INSTALL SUPPORT RAILS BEFORE MOUNTING WALL COLOR SHIELDS: REFER TO INSTRUCTION SHEET 510573. DIFFUSER WALL ANGLES ARE MOUNTED AFTER SHIELDS ARE INSTALLED AND WILL SLIGHTLY OVERLAP SHIELDS: REFER TO INSTRUCTION SHEET 510577.

**INSTRUCTIONS:**

**IMPORTANT: WALL COLOR SHIELDS ARE USED ONLY WHEN THERE IS A LENS REQUIRED IN THE R (RECESSED) POSITION.**

1. PLACE TOP EDGE OF WALL COLOR SHIELD UP AGAINST BOTTOM EDGE OF SUPPORT RAIL AND FASTEN WITH 6 PENNY NAILS OR EQUAL. LOWER EDGE OF SHIELD WILL BE HELD IN PLACE WHEN DIFFUSER ANGLE IS MOUNTED.
2. BUTT EDGES OF SHIELD AT CORNERS AS SHOWN.

