

# Electric Insulated Hot Sticks Instruction

Cut insulated  
overhead wires



Fastening  
bolt



Strip the insulated  
overhead conductor



Operate the  
ring bolts



Wrap insulation tape to  
restore insulation



1

Different tools can be switched by pulling the pin

2

Turn adapter power tools and insulation rods for quick  
disengagement and installation

