

## INSTALLATION INSTRUCTIONS FOR NWPFN/E EXIT DECAL

1. Clean lens surface with a non-abrasive solution and cloth suitable for polycarbonate; dry lens.
2. Remove adhesive liner from selected decal.
3. Apply decal to lens surface removing all air bubbles as shown below.



TYPICAL DECAL INSTALLATION

Application tip: Tape the label at the half way point (vertically) onto the surface label is to be applied to. Peel back paper backing to tape, and cut, then smooth label onto surface, working from the center out. Remove tape and apply other side in same manner.

DECAL OPTIONS:

