

HammerTap Ground Rod Connector

Installation Prep - Use a ground rod driver to drive the ground rod prior to installation in order to prevent the top of the ground rod from deforming.

Step 1 - Insert the ground wire through the tap hole of the connector.



Step 2 - With the ground wire inserted, next place the HammerTap on top of the ground rod in preparation for installation.



Step 3 - Drive the HammerTap onto the ground rod using a hammer.



Step 4 - Hammer until the nub of the HammerTap is flush with the HammerTap body. Once it is flush, the connection is complete.



For more information, check out our installation video!



Images for demonstration purposes only. Always wear appropriate PPE during installation.



A proud member of the Hubbell family.

©2023 Burndy. All rights reserved.
Hubbell and the Hubbell logo are registered trademarks or trademarks of Hubbell Incorporated.
All other trademarks are the property of their respective owners.
www.hubbell.com/burndy | Customer Service 1-800-346-4175
International 603-647-5299 | Canada 1-800-465-7051