



LIGHT KIT

INSTALLATION INSTRUCTIONS

Model No.: P2600

Vendor No.: 11221

UPC# 785247260010

1. Remove the switch housing cover on bottom of fan's switch housing.
2. Make polarized wire connection for 2 light kit wires to 2 wires inside the switch housing that are marked "FOR LIGHT", connect white to white wires and black to blue wires.(Figure 1)
3. Install the light kit assembly to the switch housing with 3 screws provided. (Figure 1)
4. Remove the lock ring from the socket by turning the lock ring counter-clockwise until it unlocks. Insert the glass into the glass holder and turn the lock ring clockwise to tighten the glass. Repeat for the remaining glass. (Figure 2)
5. With the power off, insert the light bulbs (not included) into the light kit sockets. Max. 60 watts.
6. Restore power and your light kit is ready for operation.

