



Recommended Torque Values for PCORE Test Terminals

- 1) Captive Bolts (1/2"-13) should be tightened to a torque of 40 ft.-lbs.
- 2) Corona Ring Bolts (3/8"-16) should be tightened to a torque of 20 ft.-lbs.
- 3) Terminal Clamp Bolts (1/2"-13) should be tightened to a torque of 40 ft.-lbs.

