

Installation:

Guidelines for installing your Quazite® enclosure vary depending on size, location, and environmental factors. Quazite® enclosures are designed for non-deliberate traffic areas only.

Small Enclosure Installation

1 Excavation

Excavate approximately 6 inches deeper than the depth of the enclosure. Add 6 inches of gravel or crushed rock for drainage.



2 Placement

Carefully lower enclosure into the hole until the top is at grade level.



3 Filling

Fill and compact the soil to grade level with the cover on the enclosure.



4 Adjustment

If the grade level is raised later, a straight-sided enclosure can be pulled up and bricks added at the bottom on one or four sides to conform to the landscape.

