

POUR BOX INSTRUCTIONS

(FOR USE WITH HBL SERIES ACCESS FLOOR BOXES)

Installation Instructions

CAUTION: Temporary concrete covers are intended to keep concrete residue from entering box during pour and are not intended to support loads. Replace with permanent flange/cover immediately after concrete has hardened.

CAUTION: RISK OF ELECTRICAL SHOCK. Disconnect power before installing. Never wire energized electrical components.

NOTICE: For Installation by a qualified electrician in accordance with national and/or local electrical codes and the following instructions.

NOTICE: INSURE DATA/COMMUNICATIONS ARE SEPARATED FROM POWER APPLICATIONS.

1. Make knockouts in pour box at desired locations.
2. Run conduits into the pour box.
3. Set pour box on the ground or in the slab depending on application.
4. Pour concrete until level with the lid.
5. Take lid off and discard.
6. Replace two jack screws (item E) on access floor box with longer screws provided with pour box.
7. Place AFB into the pour box (See AFB Instructions).

Hubbell Canada Inc.
870 Brock Road S.
Pickering, ON L1W 1z B
Tel: (905)839-1138
Fax: (905)839-9108

Wiring Device-Kellems
Hubbell Incorporated (Delaware)
185 Plains Road
Milford, CT 06460-8897
Tel: (203) 882-4800
Fax: (203) 882-4849



PDS-1867
11/01/05