



GROUND GRID CONNECTOR INSTALLATION INSTRUCTIONS



1) Withdraw drive screw to end point of wedge as shown.



2) Place "C" Body around conductor.



3) Place conductor designated by markings on cable nest within "C" body.



4) Insert wedge assembly while holding conductors in place.



5) Push the wedge forward to lock the conductors in place.



6) Use a 9/16" socket to drive the screw in.



7) When shear head breaks off installation is complete. Any socket, speed, or impact wrench can be used.