

PVC WATER FITTING INSTALLATION INSTRUCTIONS

PE COMPRESSION OUTLET ASSEMBLY INSTRUCTIONS

1. CUT PIPE ENDS SQUARE, DEBURR OUTSIDE AND INSIDE, CLEAN THOROUGHLY TO ASSURE THERE IS NO DIRT, GREASE, OIL, ETC. ON ASSEMBLY AREA OF PIPE.
2. LOOSEN COMPRESSION NUT UNTIL SEAL RING IS NO LONGER COMPRESSED. THEN INSERT PIPE UNTIL IT BOTTOMS IN OUTLET.
3. TIGHTEN COMPRESSION NUT UNTIL IT SHOULDERS AGAINST THE OUTLET. DO NOT OVER TIGHTEN
4. REPEAT THE ABOVE STEPS FOR ALL COMPRESSION JOINTS.

SOLVENT WELD END ASSEMBLY INSTRUCTIONS

1. SOLVENT WELD TO PIPE PER ASTM D 2855.