

Occupancy Sensors and Lighting Controls

Slide and Rotary Dimmers, and Fan Speed Controls

Preset Slide Dimmers and Rotary Dimmers with ON/OFF Switch, 120V AC



Color	Incandescent			Incandescent Rotary Push ON/OFF Dimmer		
	600W			600W		
	Single Pole, Slide to OFF	Single Pole	3-Way	Single Pole	Single Pole	3-Way
Ivory	RS600I*	RS600PI	RS603PI	RD600RI	RD600PDK**	RD603PDK**
Light Almond	RS600LA*	RS600PLA	RS603PLA	—	—	—
White	RS600W*	RS600PW	RS603PW	RD600RW	RD600PDK**	RD603PDK**

Note: *Slide to OFF series dimmers do not have an ON/OFF switch.

**Control knobs included for both ivory and white. See below for replacement slide knobs.

Fan Speed Controls, 120V AC



Color	Rocker Fan Control, 3-Speed, Slide Adjustment	Slide Fan Control, 3-Speed, Slide to OFF	Toggle Fan Control, 3-Speed	Rotary Fan Control, 3-Speed
	1.5A	1.5A	1.5A	1.5A
	Single Pole/3-Way	Single Pole	Single Pole/3-Way	Single Pole
Ivory	RDVFSQFI	RSFSQFI	RAYFSQFI	RFSQ2FDK**
Light Almond	RDVFSQFLA	RSFSQFLA	RAYFSQFLA	—
White	RDVFSQFW	RSFSQFW	RAYFSQFW	RFSQ2FDK**

Note: **Control knobs included for both ivory and white.

Replacement Control Knobs



Color	Replacement Slide Knobs	Replacement Knobs for Rotary/Push Dimmer	Replacement Knobs for 3-Speed Fan Control
Ivory	RSKI	RRKDK**	R28032406
Light Almond	RSKLA	—	—
White	RSKW	RRKDK**	R28032401

Note: **Control knobs included for both ivory and white.