



**IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.** Follow label information and instructions concerning Wet or Damp Locations, installation near combustible materials, insulation, building materials, and proper lamping. Do not install in areas subject to combustible vapors or gases. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. **All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with the National Electrical Code and local building codes.** The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. Do not block light emanating from product in whole or part, as this may cause an unsafe condition. Do not allow items such as drapes, curtains, screens or the like to come into contact with the product or to block light from the product, as this may cause an unsafe condition.

## INSTALLATION INSTRUCTIONS LITEFRAME® LFSC6EM

**CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, MAKE CERTAIN THAT THE POWER SUPPLY IS OFF BEFORE INSTALLING OR SERVICING THIS FIXTURE!**

1. Clean the Reflector surfaces that will receive the Tape. Take care not to alter appearance of the Reflector surface.
2. Roll back the plastic film from the front of the Cover Disk enough to be able to remove the plastic film easily after installation.
3. Remove the plastic backing from all pieces of the Tape.
4. Align the EM Switch Button in the Reflector with the Switch Hole in the Cover Disk, and the three Screw Alignment Marks found on the Cover Disk with three Screw Heads inside the Reflector.
5. Make sure the EM Switch Button is centered in the EM Switch Hole on the Cover Disk, and press firmly on the Cover Disk to secure the Tape to the Reflector. Make sure the EM Switch Button operates freely after installation of the Cover Disk.
6. Completely remove the plastic film from the front of the Cover Disk.



**CAUTION: DO NOT ATTEMPT TO MODIFY OR REWIRE FACTORY INSTALLED WIRING ON THE FIXTURE. SAFETY AND PROPER OPERATION OF THE FIXTURE DEPEND ON THE INTEGRITY OF THE WIRING.**

**KEEP THESE INSTALLATION INSTRUCTIONS**



® **701 Millennium Blvd, Greenville, SC 29607**  
With representatives offices in principal cities throughout North America.  
Copyright 2018, 6/21/18, All Rights Reserved - Printed in U.S.A.