


Maintenance Bulletin for PT55E/EF-100E/EF



Item	Description
1	Outer Link
2	Inner Link
3	Anti-friction Plate
4	Bar Carrier (Customer Specified Part Number)
5	Whiz-Lock Bolt
6	Hinge Pin
7	Retaining Ring
8	Mounting Bracket, L.H.
9	Mounting Bracket, R.H.

Tools Required: Retaining Ring Pliers, Socket/Wrench Set

Removal Steps

- 1. Pull retaining pin (7) off hinge pin (6) using retaining ring pliers
- 2. Remove hinge pin
- 3. Remove anti-friction plate (3)
- 4. Slide chains, both outer (1) and inner (2) apart
- 5. Repair/replace any components as required. Carrier removal will require socket/wrench set

Installation Steps

- 1. Slide chains (1,2) together to form a clevis
- 2. Insert anti-friction plates (3) at each join between outer link and inner link (2 per joint)
- 3. Insert hinge pins (6) (3 per joint)
- 4. Install retaining pin (7) onto hinge pin with retaining ring pliers

