

**Parts List
for
Foot Switch C417-0337**

Item No.	Description	Part No.	Qty.
1	Housing	P308-0706	1
2	Switch	P308-0708	1
3	Cord Assy. 15 ft.	T308-0870	1
4	Cord Assy. 5 ft.	T308-0871	1
5	Cover	P308-0707	1
6	Retaining Ring	P308-0709	1
7	Screw	P001-1488	2
8	Nut	P001-1199	2

