



For technical assistance call RigPower at: 225-272-8800  
or e-mail Gil@RigPower.com

WARNING: THE SECURE MOUNT® & SAFE STAB® SERIES IS NOT DESIGNED FOR INTERRUPTING CURRENT. DO NOT CONNECT OR DISCONNECT THE CIRCUIT WHILE LIVE. FOR PERSONNEL SAFETY, THE PANEL MOUNTED RECEPTACLE MUST BE COVERED BY A SAFETY CAP (if applicable) WHEN A CABLE IS NOT CONNECTED.

### Application Information

The Secure Mount® & Safe Stab® Series connectors have been designed to safely distribute 1135 Amps @ 1000 Volt AC or DC power. These connectors are rated for 1135 Amp continuous operation at 125°C.

### Installation of Secure Mount® & Safe Stab® Panel Mounts

1. Drill mounting pattern as shown below into a non-ferrous panel of 0.50 inch minimum thickness.
2. Install Panel Mount into non-ferrous panel using appropriate hardware and supplied gasket.
3. Insure that warning label is located on upper right hand corner of panel mount.
4. Insure retention lanyard for safety cap is installed on lower right hand mounting bolt.
5. Install safety cap on receptacle prior to connecting rear wiring.

### Mounting Pattern:

