


# POLE KEY ANCHORS

## Application/Installation

<b>ANCHOR APPLICATIONS</b>	For reinforcing poles at the ground line where load is unbalanced in soft soils or in areas subjected to constant high winds.
<b>INSTALL IN THESE CLASS SOILS</b>	Classes 3, 4, 5 and 6 (200-600 inch-pound with soil test probe)
<b>INSTALLING EQUIPMENT REQUIRED</b>	Extra anchor rod, expanding bar and shovel.
<b>LIMITATIONS ON USE</b>	Will not take the place of guying on a heavily-loaded structure.


### STEP #1

Straighten the pole.



### STEP #2

Attach anchor to 3/4" Expanding Anchor Rod. Lower anchor assembly into pole hole (beside the butt of pole) and bust anchor open with the Expanding/Tamping bar.



*NOTE: If desired, a second pole key anchor may be used at the top (ground level) of the hole on the opposite side*




**CHANCE**<sup>®</sup>

# HOW TO USE EXPANDING POLE KEY ANCHORS

## STEP #3

Remove rod from anchor and hole.  
Backfill and tamp hole.



**CHANCE**<sup>®</sup>