

HUBBELL CATALOG NO. HBLWLC

INSTALLATION INSTRUCTIONS

1. FOR EXISTING INSTALLATIONS, REMOVE LIFT COVER ASSEMBLY ① AND OLD GASKET ② AND DISCARD. CLEAN SEALING SURFACE.
2. INSTALL (1) GASKET ③ BETWEEN LIFT COVER ASSEMBLY ① AND LOCKING BRACKET ASSEMBLY ④.
3. INSTALL (1) GASKET ③ ON BACK OF LOCKING BRACKET ASSEMBLY ④.
4. SECURE ASSEMBLY TO BOX USING SCREWS ⑤ SUPPLIED WITH LOCKING BRACKET.

