

Installation Instructions

SLS-V2:

The door/visor assembly does not ship in the same carton as the reflector assembly.

1. Obtain door/visor assembly and the reflector assembly.
2. Remove the screw and nut from the door/visor hinge.
3. Align the holes in the door assembly hinge to the holes in the hinge on the reflector.
4. Insert the screw, that was removed in Step 2, through the holes of both hinges and install the nut. Tighten only until a few threads protrude through the nut. Do not over-tighten.

Use door/visor, SLS-V2 Series, with reflector RRx-V2 Series or use door/visor, SLS-V2 Series, to complete the assembly of the SLS Luminaire.

