


## **BDBMCS5MA, Flex Rated Power Distribution Block Adder**

Bv Burndv Catalog # BDBMCS5MA

POWER DISTRIBUTION BLOCKS.

## General



Conductor Type

• AL C Str-Run



CU C Str-Run

Catalogs - BURNDY Master Catalog - Full Line BURNDY Catalog Installation Manuals - 50130772 - Adder Instructions Interactive Catalog - BURNDY Full-Line Digital Catalog Sales Drawings - 50063030 Specifications - BDBMCS5MA

