



### Sensors connected in parallel loops

Notes:

1. Lights turn ON only after manual button is pushed.
2. Lights turn OFF only after BOTH sensors time out.
3. This is a ground-leakage powered sensor. It must be grounded to function.

IWSZPM in a 3-way Configuration



**Building Automation, Inc.**