


Note:

1. Sensor is shipped with all dip switches in the OFF position (Factory Default)



LHIRS1 Wiring Diagram



Building Automation, Inc.