

LXBASM for Building Automation Interface with LXJENSYS for Web Browser Access

Install per Installation Instructions.

LXBASM Connected to LXJENEsys on an LX Network

THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL BUILDING AUTOMATION ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.

HUBBELL Building Automation
(888) 698-3242
(512) 450-1100
9601 Dessau Rd. - Bldg 1
Austin, Tx 78745