

**austdac**<sup>®</sup>  
**TROLEX**

# COMPLIANCE PAC K<sup>+</sup>

QUICK START  
GUIDE

Register your warranty online  
at [www.trolex.com/register](http://www.trolex.com/register)

**XXD1<sup>+</sup>**

## 1. XCD1+ REQUIRES COMPLIANCE CHECK

The flashing lights shown and an intermittent audio beep tell you your XCD1+ is ready for a compliance check.



TROLEX

# BreatheLITE

© Trolex LTD  
All Rights Reserved

## 2. DOWNLOAD

Download the **BreatheLITE** software on to your Mac or PC device.

 [trolex.com/breathelite-download](https://trolex.com/breathelite-download)

### 3. CONNECT

Connect your **XC1+** directly to your computer using the USB cable.



### 4. COMPLIANCE BASE

Place your **XC1+** in a Trolex compliance base ready for the compliance check.

Ensure the clear hood is fitted over the top and the unit is connected to your computer.

## 5. PREPARE SAMPLE

Decant the Trolex approved sample into the application bottle.



## 6. START YOUR CHECK

Select "Compliance check" on **BreatheLITE**.



## 7. SAMPLE

Introduce sample and follow the on-screen instructions.



## 8. PASSED

Great, you're good to go for another 3 months.



\*Please consult the user manual if you need to retest your **XO1+**.

## 9. DON'T FORGET

You can order more compliance samples through your local approved distributor.



**austdac**

Unit1, 42 Carrington Rd, Castle Hill, NSW, 2154

**E:** [customerservice@austdac.com.au](mailto:customerservice@austdac.com.au)

**T:** 1800 568 984 **W:** [www.austdac.com.au](http://www.austdac.com.au)