

**TO REMOVE SHIELDING**

STE Stratus series and TRA Transition series open lens fixtures use curved plastic light seals mounted to each endplate of the fixture to support the perforated metal (MPO) and the acrylic open (CLO) lenses.

To remove baskets or open lenses, lift the end of the shielding gently off the curved light seal at each end of the fixture. Remove and re-install the shielding handling by the ends only. A 3/8" solid strip of metal at the ends of perforated metal baskets provides additional rigidity to flex ends over the light seals. To avoid distorting the shielding DO NOT HANDLE or apply force to the center or to the long sides of the shielding.



Allow opposite edge of basket to hinge on light seal during lamping and fixture maintenance. To replace baskets, refasten both ends of the shielding over the light seal.



Part #: 93041413