



GAI-TRONICS CORPORATION

XMLS001A Multi-line Select Option

Field Installation Kit Instructions

Confidentiality Notice

This manual is provided solely as an operational, installation, and maintenance guide and contains sensitive business and technical information that is confidential and proprietary to GAI-Tronics. GAI-Tronics retains all intellectual property and other rights in or to the information contained herein, and such information may only be used in connection with the operation of your GAI-Tronics product or system. This manual may not be disclosed in any form, in whole or in part, directly or indirectly, to any third party.

General Information

The XMLS001A Multi-line Select Option for the IPE2500A allows the user to connect up to four tone remote control lines to one desk set. This kit includes the following components:

Qty	Description
1	PCBA, 69297-003 Multi-line Select
4	Phillips head screws, 4-40 × 1/4
4	Washers, #4 × 9/32
1	Cable Assembly, 61531-017 (4 conductor; 2 connector)

Installation

Equipment needed for this installation is as follows:

- Static-neutralized work surface and a wrist strap for the installer
- #1 Phillips screwdriver
- #2 Phillips screwdriver
- XAC0100A, Mounting Bracket with Options Interface Cable (50C005-02) and associated mounting screws.

Open the Desk Set Housing:

1. Invert the IPE2500A Desk Set on the anti-static surface and remove the four screws in the cavities in the bottom half of the housing.
2. Holding the top and bottom halves together, turn the desk set right side up.
3. Separate the top from the bottom, laying the top half face-down to the left of the bottom. If the desk set is already equipped with the mounting bracket then proceed to mounting the Multi-line Select (MLS) PCBA.

 **NOTE**  The NDC option (DC control generator PCBA) and/or the NRC Option (relay control PCBA) are not compatible with the MLS, and must be removed before the MLS can be installed.

Installing the Mounting Bracket:

4. Position the bracket on the floor of the desk set bottom with the folded edges of the bracket facing down and the notch on the left side (opposite the steel weight).
5. Using the #2 Phillips screwdriver, secure the bracket with the two course-threaded screws going into the plastic bosses protruding up from the bottom housing.

Mounting the MLS PCBA:

6. Secure the MLS PCBA to the bracket using the four machine screws.
7. Connect the 14-conductor ribbon interface cable to the J700 on the DTD (main) PCBA in the desk set top. Choose the end of the cable with the single connector for this.
8. Connect the remaining end of the ribbon cable to P800 on the MLS PCBA, choosing the inner connector on the cable rather than the one at the very end.
9. Connect the four-conductor ribbon cable between P802 on the MLS PCBA and P802 on the DPS PCBA (on the desk set bottom)

Re-assemble the Desk Set Housing:

10. Replace the top half on to the bottom taking care to fold the ribbon cables neatly away from interfering features, most notably the magnet holder protruding out from the underside of the handset cup on the top half.
11. Hold the two halves together while you turn the desk set face down on the work surface. Re-insert the four housing screws into the cavities and tighten until snug.
12. Installation complete. Program the desk set for the desired line features using the CARD Suite Software.

Be sure to give the Operation Instruction Manual to the customer.