

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Follow label information and instructions concerning Wet or Damp Locations, installation near combustible materials, insulation, building materials, and proper lamping. Do not install in areas subject to combustible vapors or gases. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. **All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with the National Electrical Code and local building codes.** The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. Do not block light emanating from product in whole or part, as this may cause an unsafe condition. Do not allow items such as drapes, curtains, screens or the like to come into contact with the product or to block light from the product, as this may cause an unsafe condition.

INSTALLATION INSTRUCTIONS 4W1, 4W1ST TRIM

A. Lamp Installation:

1. Loosen horizontal and vertical locking Thumb Screws (1) & (2) and rotate Lamp Mounting Plate (3) to 0 degrees vertical. Rotate vertical locking thumbscrew clockwise and lock Lamp Mounting Plate into place in this position.
 2. Install lamp into Socket. (4)
 3. Install Lamp (5) into Lamp Holder Bracket (6).
- NOTE: If diffused lens (7) is required, install between (5) and (6).

B. Trim Installation:

1. Remove screw (10), pull Safety Cable (7) through opening in Plaster Frame and attach to Trim as shown using Screw (10).
2. Squeeze the two Torsion Springs (8) together and insert ends into slots on both Brackets (9) as shown.
3. Push Trim towards ceiling until springs force the Trim against the ceiling line.

C. Horizontal Adjustment:

1. Make final horizontal adjustment by holding outer flange on Trim and rotating horizontally.
- NOTE: If necessary, pull the flange away from the ceiling slightly before rotating.
2. Pull Trim away from ceiling and tighten locking Thumb Screw (1) after adjustment.

