
# Cable Gland Assembly Instructions PPSG 553/RAC





# **B: Cable Preparation**


Slide shroud (if included), backnut (6), middlenut (5) and armour clamp ring (4) onto cable.

Confirm orientation of armour clamp ring is correct (see table below).

Cut cable length, strip outer sheath and cut armour/braid to lengths as shown below.

Then expose the conductors by stripping the inner sheath as a minimum to the start of the armour/braid.

If drain wires or screens are to be brought through the barrier seal then refer to AI2028 for preparation instruction.




# **C: Installing Cable Gland**


# STEP 1: Fit Armour To Spigot

Al2051 - Issue D / June 2024 / Page 1 of 4

Slide spigot (3) over cable. Push armour/braid up to spigot shoulder. Slide clamping ring (4) up to the armour/braid by hand.








## STEP 3: Clamp Armour/Braid

Slide middlenut (5) up to entry and hand tighten.

If not already screwed into equipment, grip the entry (1) with a spanner/wrench. Use a second spanner/wrench to tighten half to three guarters of a turn.




## Tip: Support the cable to prevent it twisting.

#### STEP 4: Inspect Armour/Braid


Unscrew the middlenut (5). The armour clamp ring (4) should now be locked in place.

Visually inspect that the armour/braid has been successfully clamped between the spigot (3) and the armour clamp ring (4). If clamping is not satisfactory, repeat step 3.



### **STEP 5: Prepare Seal for Installation**


For all seal positions which are to be populated with conductors, cut the diaphragms down as per the instructions below. For this, Hawke recommends the use of flush cable cutters. All unused positions must be left capped.



**Critical Note** Applies to C-Size Seal Only The 7x indicated positions above **must** be populated with conductors.

Hawke recommends that the seals are populated from the centre positions first, and are evenly distributed as much as possible to ensure consistent compression.


Examples of good and bad practice:





#### **STEP 6: Install seal onto Conductors**


Feed each conductor into the correct seal diaphragm position. Ensure the diaphragm cone is in complete contact with the conductor around the full diameter. If the seal is ripped during this process, and the cone is not in complete contact with the conductor, then the seal must be replaced.




#### STEP 7: Install barrier seal into Entry

Fit entry (1) to enclosure. If required, use the appropriate IP washer.

Feed the conductors through the entry (1) and seat the seal (2) into the entry (1) until it meets the base of the entry bore.






#### **STEP 8: Compress Barrier Seal**

With the seal fully seated into the entry, tighten up the middle nut by hand until resistance is felt.

Using a wrench/spanner tighten the middlenut (5) the correct number of turns, refer to barrier seal compression table.




Barrier Seal Compression											
Gland Size	Seal Type	No. of Turns									
Os - O	Standard	2									
A	Standard	3									
В	Standard	5									
В	Alternative (S)	4									
C	Standard	3									

#### **STEP 9: Install Backnut**

Tighten the backnut (6) until a seal is formed around the cable.

Use a wrench/spanner to grip the middlenut (5).

While preventing the middlenut (5) turning, use a second wrench to apply one further full turn to the backnut (6).



AI 2051 - Issue D / Page 3 of 4


# Technical Information PPSG 553/RAC



#### STEP 10: Inspect Backnut

Use the middlenut (5) guide as an indication that the backnut (6) is in the correct position to suit cable diameter. A diameter scale below is provided to assist this process.

Slide shroud over cable gland if applicable.



Shroud (If applicable)

### TECHNICAL DATA Cable Gland Type:

Equipment Type:Group II Barrier Cable GlandsIngress Protection:IP66, IP67, IP68\*\*30m for 7 days with thread sealant to<br/>EN60529, See Al464.

P PSG 553/RAC

-60°C to +100°C

#### **Operating Temp:**

#### **CERTIFICATION DETAILS**

Ex db IIC Gb / Ex eb IIC Gb /Ex nR IIC Gc / Ex tb IIIC Db									
ATEX:	CML19ATEX1167X	UKEX: CML 21UKEX1161X							
IECEx:	CML19.0045X	IEx:14.0272X							
EAC:	No EA3C RU C-GB.HA91.B.00	264/21							

#### ACCESSORIES

Hawke offer the following accessories to enable correct sealing and ground of cable gland.

Shroud:For additional corrosion protectionLocknut:To secure gland into positionSealing Washer:For additional ingress protectionEarth Tag:For external bonding pointSerrated Washer:To prevent vibration loosening lockHawke GMC:Gland mounted cable clamp

#### INSTALLATION NOTES

1. Hawke cable gland entry threads are manufactured in accordance with Metric BS3643 (Metric) or ANSI/ASME B1.20.1 (NPT).

2. All cable glands must be installed by a suitably trained and competent individual. 3. When specifying cable glands, the installer should check material compatability with enclosure and environment.

4. In order to maintain effective sealing of an IP washer, cable gland entries must be installed perpendicular to the enclosure sealing faces and the enclosure sealing face must be smooth and free from damage.

5. For drain wire preparation please refer to AI2028 "Method 1".

#### SPECIAL CONDITIONS OF USE:

1. When used with unarmoured or braided cables, this cable gland is only suitable for fixed installations, the cable for which must be effectively clamped to prevent pulling and twisting. Does not apply when fitted with Hawke Gland Mounted Clamp (GMC) 2. When the glands are used for increased safety or dust protection the entry thread shall be suitably sealed (in accordance with IEC 60079-14) to maintain the ingress protection rating of the associated enclosure. Not applicable when Hawke IP66/67 seal is used.

#### **TORQUE VALUES**

For external bonding point All torque values below were generated on metallic mandrels. For cable, it is To prevent vibration loosening locknuts recommended that the assembly instructions are followed.

Torque Figures N/m												
Gland Size	Os	0	А	В	B (alt)	С						
Middlenut Torque	7	7	7	15	27	27						
Backnut Torque	12	12	20	30	35	35						

	CABLE GLAND SELECTION TABLE																			
Size Ref.			Cable Acceptance Details																	
				Conductors							Steel Wire Armour/Tape/Braid				Outer Sheath				Hexagon Dimensions	
			Standard Seal			Alternative Seal (S)			е	Standard Ring		Alternative Ring (AR)		Diameter		essed Jth	mum gth	Dimensions		
	Metric	NPT		Diameter (mm) Quantity		antity		Diameter (mm) Quant		antity	Orientation	Orientation	Orientation	Orientation	Min	Max	Compressed Length	Maximum Length	Across	Across
		INFI	Min	Max	Min	Max	Min	Max	Min	Max	1	2	1	2		ax			Flats	Corners
Os	M20 / M16	1⁄2"	1.5	4.0	1	4	-	-	-	-	0.8 - 1.25	0 - 0.8	-	-	5.5	12.0	52.0	81.0	24.0	26.5
0	M20 / M16	1⁄2"	1.5	4.0	1	4	-	-	-	-	0.8 - 1.25	0 - 0.8	-	-	9.5	16.0	52.0	81.0	24.0	26.5
А	M20	1⁄2" / 3⁄4"	1.5	4.0	1	7	-	-	-	-	0.8 - 1.25	0 - 0.8	-	-	12.5	20.5	53.0	83.0	30.0	32.5
В	M25	3⁄4" / 1"	1.5	4.0	1	12	4.5	6.5	1	5	1.25 - 1.6	0 - 0.7	0.9 - 1.25	0.5 - 0.9	16.9	26.0	59.5	95.0	36.0	39.5
C	M32	1" / 1¼"	1.5	4.0	7	19	-	-	-	-	1.6 - 2.0	0 - 0.7	1.2 - 1.6	0.6 - 1.2	22.0	33.0	64.0	98.0	46.0	50.5

EU Declaration of Conformity in accordance with European Directive 2014/34/EU and UK Statutory Instrument 2016/1107

Ianufacturer: Hawke International, Oxford Street West, Ashton-under-Lyne, OL7 0NA, United Kingdom

Equipment: P PSG/553/RAC

Provisions of the Directive fulfilled by the Equipment: Group II Category 2GD Ex db eb IIC Gb, Ex nR IIC Gc, Ex tb IIIC Db – IP66 67 Harmonized Standards used: EN 60079-0:2018, EN60079-1:2014, EN60079-7:2015+A1:2018, EN60079-15:2019, EN60079-31:2014

Notified Body for EU-Type Examination: CML B.V. 2776 Amsterdam, NLD EU-type Examination Certificate: CML19ATEX1167X, CML19ATEX4507X (Ex nR) Notified Body for production: 0598 Approved Body for UK-Type Examination: CML B.V. 2503 Chester, UK UK-type Examination Certificate: CML 21UKEX1161X, CML21UKEX4133X (Ex nR) Approved Body for production: 1180

On behalf of the above named company, I declare that on the date the equipment, accompanied by this declaration, is placed on the market the equipment conforms with all technical and regulatory requirements of the above listed directives.



Hawke International UK Oxford Street West, Ashton-Under-Lyne, Lancashire, OL7 0NA, UK Tel: +44 (0) 141 810 9644 Web: www.hubbell.com/hawke E-mail: hhsales@hubbell.com

Hawke International is a division of Hubbell Ltd. Registered No. 669157 in England. Registered Office: Cannon Place, 78 Cannon Street, London EC4N 6AF.