



In most cases Designer series are shipped assembled.

\*Note the receptacles and the concrete slab should be prepared and fully cured before the enclosure is unpackaged.

1. Position the enclosure over the equipment and the receptacles (if heat is required).
2. Locate the interior anchors. Mark and drill 3/8" diameter holes x 2" deep with the supplied bit.
3. Drive the wedge anchors into the holes and tighten with the washer and nut.
4. Hang the heater (if required) on the factory mounted heater plate and plug into a G.F.I. protected receptacle.
5. Attach a padlock (not included) to each hasp and staple to secure.

**Warning! A ground fault circuit interrupting device shall be installed in the electrical supply circuit to the heater(s). Failure to do so may result in injury or death. The interior of this enclosure is a damp location.** Contractors other than Hot Box are responsible for the installation of the G.F.I. protected service and receptacles. When multiple heaters are required it is recommended that each 1000w, 1500w or 2000w convection heater be on separate 20 amp circuits so in the event a circuit fails, all other circuits will remain powered. All installations to be in accordance with the local and national codes.

Hot Box  
3621 Industrial Park Drive  
Lenoir City, TN 37771

Contact Information  
Phone: (800) 346-3062  
waterhlc@hubbell.com  
www.hot-box.com