



**KILLARK®**

## INSTALLATION, OPERATION & MAINTENANCE DATA SHEET

**B7NFD2-RPH B7 DISCONNECT HANDLE ASSEMBLY**  
For use in Class I, Groups B, C & D, Type 3, 4 & 4X  
and Class II, Groups E, F & G, and Class III Hazardous  
Locations, as defined by the Canadian Electrical Code  
and the National Electrical Code

**READ THIS SHEET CAREFULLY BEFORE BEGINNING INSTALLATION**



# B7NFD2-RPH B7 DISCONNECT HANDLE ASSEMBLY

### **CAUTION:**

Before installing, make sure you are compliant with area classifications, failure to do so may result in bodily injury, death and property damage. Do not attempt installation until you are familiar with the following procedures. All installation must comply with the applicable Electrical Code.

Make sure that the circuit is de-energized before starting installation or maintenance.

Verify that the installation is grounded. Failure to ground will create electrical shock hazards, which can cause serious injury and or death.

### **IMPORTANT:**

This device **must** be installed by trained, qualified and competent personnel. Installation must comply with local, state and national regulations, as well as safety practices for this type of equipment.

Technical information, advice and recommendations contained in these documents is based upon information that Killark believes to be reliable. All the information and advice contained in these documents is intended for use only by persons having been trained and possessing the requisite skill and know-how and to be used by such persons only at their own discretion and risk. The nature of these instructions is informative only and does not cover all of the details, variations or combinations in which this equipment may be used, its storage, delivery, installation, check out, safe operation and maintenance. Since conditions of use of the product are outside of the care, custody and control of Killark, the purchaser should determine the suitability of the product for his intended use, and assumes all risk and liability whatsoever in connection therewith.

**KILLARK®**

**Chalmit**

**Victor**  
Lighting

**Vantage**  
Technology

**RIG POWER**

**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113

P/N KIL00921366 FORM NO. K1366 09/10 ERO-4-013-10


Page 1 of 2

**WARNING:** Electrical power **must** be **OFF** during installation, or performing any maintenance. **Disconnect** primary power source and **lock out**.

**NOTE:**

1. Apply not to threads of bushing assembly.
2. Screw bushing assembly into cover before attaching handle.
3. When handle is in the "off" position, the slotted side of the rotary operator should be parallel to the long side of the cover, (as shown in picture).

**B7NFD2-RPH BUSHING ASSEMBLY**



ITEM	P/N	DESCRIPTION
1	21847AAAB	B7EP SHAFT
2	0330100B	3/16" ID O-RING
3	21836AAAB	B7EP/EO BUSHING
4	0692425B	RETAINING RING

ITEM	P/N	DESCRIPTION
1	17200AAAB	B- 32 PAN HD SCREW
2	D04750H02	HANDLE
3	P686402	ON-OFF ECSUTCHEON
4	19316AAAB	5 / 32 SPRING PIN
5		BUSHING ASSEMBLY
6	1203	SEALING LOCKNUT
7	21846AAAB	ROTARY OPERATOR
8	17233AAAB	8- 32 PAN HD SCREW

**B7NFD2-RPH HANDLE ASSEMBLY**

