

Installation Instructions for Enhanced Ground Rod Vertical Shaped Model

Ground Preparation:

- Bore a 4" diameter hole (minimum) 6" deeper than the length of the enhanced ground rod.

Chemical Ground Rod Preparation:

- Remove the black sealing tape from the bottom section of the ground rod just before placing ground rod into the trench.
- Do not remove the black sealing tape from the top section of the ground rod.

Installation:

- If using Contact-GM ground enhancement material, cover the bottom of the hole with approximately 6" of material.
- Insert ground rod into the hole.
- Connect tail to the ground system.
- Fill the hole with the rest of Contact-GM material. Do not fill past the backfill marker.
- Remove the black sealing tape from the top portion of the shaft. Do not cover the breather holes with backfill.
- It is recommended that a test well be placed around the top part of the ground rod. This serves to protect the top of the unit and helps prevent debris from blocking the breather holes.

