

Installation Instructions for Enhanced Ground Rod Horizontal L-Shaped Model

Ground Preparation:

- Dig a Trench 4" wide by 30" deep, making sure there is a slight slope going away from the ground rod's vertical shaft.

Chemical Ground Rod Preparation:

- Remove the black sealing tape from the bottom / horizontal section of the ground rod just before placing ground rod into the trench.
- Do not remove the black sealing tape from the top / vertical section of the ground rod.

Installation:

- If using Contact-GM ground enhancement material, cover the bottom of the trench with approximately 1" of material.
- Insert ground rod into the trench.
- Connect tail to the ground system.
- Cover the ground rod with the rest of Contact-GM material.
- Remove the black sealing tape from the top / vertical portion of the shaft. Do not cover the breather holes with backfill.
- It is recommended that a test well be placed around the top part of the ground rod. This serves to protect the top of the unit and helps prevent debris from blocking the breather holes.

